

OTHER ACCESSORIES



Dual Axis Stand
Adapter

Parts & Accessories Table

Description	Item	Description	Item
Shoe Mount Adapter	2630	Single Axis Stand Adapter	3860
Pole	4000	Dual Axis Stand Adapter	3865
Storage Sack	4511		



2812 Speedlight Portrait Kit for Profoto A1 & Godox V1

Instructions for Care and Use



Assembly

1. Attach ring & shoe to bracket using the two plastic handled thumb screws.

Note: the star handle screws into the shoe

and the round handle screws into the ring.



2. Construct the Lightbank by inserting the poles into the bank and inserting the ends into the ring. Once the Lightbank is fully erect, attach the diffusion front screen.



3. The Lightbank assembly can be mounted to any light stand with either 3/8" or 1/4-20 screw adapter via the round thumbscrew. Remove the threaded reducer, using a flat screwdriver for 3/8".



4. Attach your Speedlight to the shoe and shoot.



Disassembly and Storage

Disassemble in reverse order of assembly. The Lightbank poles can be left in the Lightbank and rolled prior to placing in its storage sack.

Tips for Care and Use

Cleaning - Your Chimera Lightbank can be cleaned by hand washing with cold water, a sponge and mild soap. Do not machine wash. To dry, assemble the Lightbank onto a Speed Ring and completely air dry.

Repair - Chimera has an expert in-house repair department. Lightbanks need to be clean, with any added tape removed before sending in for repair. If the Lightbank is received in dirty or in taped condition, the repair may be refused and returned to the sender. Please call in advance to get a Return Authorization Number and repair estimate at 888-444 1812.

Warranty Information

At Chimera, we stand behind our Lightbanks, speed rings, and light control accessories with a limited 5-year warranty against manufacturing defects in materials, workmanship, and color stability. If our products are not fully operational out of the box or if they fail to perform within five years from the date of purchase, return it for repair or replacement at no charge. Of course, Chimera's warranty cannot cover damage caused by accidents, improper care or use, or the natural deterioration of materials over an extended period of time. This warranty does not apply to expendables, such as light bulbs, and certain OEM products.